

## **CE790 GUI Release Notice**

**Firmware Version: v2.1.204**

**Date: 2011-01-14**

The CE790 Digital KVM Extender now supports Graphical User Interface (GUI) operation and the AP is available for download. A separate CE790 GUI User Manual is also available for download. This supplements the CE790 User Manual.

**Note:** The CE790 Browser GUI is a WinPcap-based application. WinPcap is the industry-standard tool for link-layer network access in Windows Environments, and must be installed on your PC before installing the CE790 GUI AP. For further information, go to [www.winpcap.org](http://www.winpcap.org) and see the detailed instructions in the CE790 GUI User Manual.

### **To download the CE790 AP:**

1. Download the CE790 AP from the ATEN website [<http://www.aten.com/download/download.php>].
2. Save the file to a convenient location.
3. Click on the file to open the CE790 GUI. Detailed GUI operating instructions can be found in the CE790 GUI User Manual.

### **To download the CE790 GUI User Manual:**

1. Download the CE790 GUI User Manual from the ATEN website [<http://www.aten.com/download/download.php>].